

SCHOCK Eco Granit Sink Cleaning Instructions

Archant is dedicated to ensuring the longevity and quality of our products is upheld. This guide provides care and maintenance tips for your Archant sink.



For expert advice on our products, please call
archant.co.nz 0800 ARCHANT (0800 272 4268)

Daily Cleaning

- Your Ordinary Dishwasher Liquid- great for everyday cleaning, apply with warm water and the Eraser sponge
- Eraser Sponge- great for everyday cleaning, also great to help get rid of marks left by metal pots etc. Just add water & Dishwasher liquid. White sponges can also be purchased from M10 and many supermarkets. They are called magic sponges in the supermarkets
- Microfibre Cloths - The micro fibre cloths to recommend are 'Filta microfiber cloths', available at supermarkets. Trick is to only use with water (not spray and wipe) and make sure it's only damp not wet. If wet you have to dry, if damp it will dry quickly with no streaks

Long-term build-up of water marks and deposits are prevented by daily cleaning and drying. Warranty can be void if daily cleaning routine is not maintained.

More Intensive Clean for removing stubborn marks or limescale build up

1. Dishwash Tablet – we recommend the Finish Brand (alternatively 2-3 teaspoons of Finish dishwasher powder) - Place two tablets in the sink & partly fill the sink with warm 60 degrees water. Fill to about 2cm.
2. Stir in until completely dissolved
3. Leave for a minimum of 6 hours, or overnight if possible for best results
4. Empty the sink & using the Eraser sponge, scrub the bowl out thoroughly
5. Rinse well with fresh water & completely dry with an ordinary cleaning cloth
6. Leave 30 minutes
7. We recommend that once the marks have been removed to a satisfactory level, that the easy care balsam maintainer is applied. This will help to keep the sink cleaner for longer (and make it easier to clean) especially with white sinks – also helps to make the water sheet off the sink (like a wax coating on a car)

For Extra Protection

- Easy Care Balsam Maintainer- this is to help the sink stay cleaner for longer especially with white sinks – also helps to make the water sheet off the sink (like a wax coating on a car)
- Brightener- this is designed to be used on White sinks, this is to be used as a maintainer cleaner periodically keeping the sink sparkling for years to come. (This is available to purchase separatel brightener can be applied before the easy care balsam. This is a bleach type cleaner. (wear gloves)
- Remember: do not use bleach, or abrasive cleaning pads or creams (JIF)



**Magic Cleaning
Sponge**
20.9728.ZZ



**Easy Care Cleaning
Kit - Small**
20.9727.ZZ



**Easy Care Cleaning
Kit - Large**
20.9677.ZZ